

Investigation of the expansion of battery cells with chromatic confocal distance sensors under varying mechanical stress

D.Nusko^{1,2}, T. Krause^{3,4}, L. Pitta Bauermann¹, M. Kroll¹, S. Dsoke^{1,2}

¹ Fraunhofer Institute for Solar Energy Systems ISE, Heidenhofstr. 2 79110 Freiburg, Germany


² Albert Ludwig University of Freiburg, Faculty of Engineering Department of Sustainable Systems Engineering – INATECH, Emmy-Noether-Str. 2, 79110 Freiburg, Germany

³ Precitec GmbH & Co. KG, Draisstraße 1 76571 Gaggenau, Germany

⁴ RWTH Aachen University TOS – Chair for Technology of Optical Systems, Steinbachstraße 15, 52074 Aachen, Germany

Abstract



Actual quality control in battery cell manufacturing includes measuring the electrical behavior of a produced cell [1,2]. Additional optical, non-contact measurements of the expansion behavior of cells performed simultaneously with the electrical measurements can provide deeper insights about the quality of the cells. To investigate the expansion behavior of 1 Ah NMC622 Li-ion pouch cells during cycling, measurements were made using digital image correlation technique on non-compressed cells, as well as measurements using chromatic confocal distance sensors on compressed cells.




3D distortion image taken with DIC system at the beginning of a charging cycle (left) and at the end of the charging cycle (right)

Voltage and dilation measurements of battery cells with different surface pressures. Top: Voltage curve of the individual measurements over time. Below: Dilation over voltage measured with chromatic confocal distance sensors with clamped cell surface and DIC with unclamped cells

Measuring principle of DIC [3]



Measuring principle of chromatic confocal distance sensor [4]



Conclusion and Outlook

- Compressed cells show results with lower deviation and less dilation than uncompressed cells
- Due to large file sizes of DIC, chromatic confocal distance sensors can have higher sampling rates
- DIC has higher potential to measure unclamped cells due to bigger region of interest
- Long-term data with chromatic confocal distance sensors should be recorded to detect irreversible expansion and aging behavior of battery cells
- Cells with defined defects should be measured in compressed condition for comparison with non-defect cells

Experimental

Battery Cell

- 1 Ah NMC622 / Graphite
- 2 single sided / 8 double sided cathode sheets
- 2 single sided / 8 double sided anode sheets
- Size 66 x 51 x 3 mm³ (L x W x H)

Digital Image Correlation (DIC)

- Two cameras with defined angle focus on same area of interest
- 3D deformation can be measured by recording stochastic pattern on a surface through a digital image sequence
- Image sequences are combined using the photogrammetric theories

Chromatic confocal distance sensor

- White light source focused along a single propagation axis
- Light wavelength, which is focused on the surface, is reflected to sensor
- Distance to workpiece determines reflected wavelength intensities
- Contactless distance measurement

Kontakt

M.Sc. Daniel Nusko
TestLab Batteries
Electrical Energy Storage
Tel. +49 761 4588-5425
daniel.nusko@ise.fraunhofer.de
Fraunhofer ISE
Heidenhofstr. 2
79110 Freiburg
www.ise.fraunhofer.de

[1] D. L. Wood, J. Li and S. J. An, "Formation Challenges of Lithium-Ion Battery Manufacturing," *Joule*, Jg. 3, Nr. 12, S. 2884–2888, 2019

[2] A. Weng et al., "Predicting the impact of formation protocols on battery lifetime immediately after manufacturing," *Joule*, Jg. 5, Nr. 11, S. 2971–2992, 2021

[3] J. Luo et al., "In-situ measurements of mechanical and volume change of LiCoO₂ lithium-ion batteries during repeated charge–discharge cycling by using digital image correlation," *Measurement*, Jg. 94, S. 759–770, 2016

[4] M. Agoyan et al., "Confocal chromatic sensor for displacement monitoring in research reactor," *EPI Web Conf.*, Jg. 253, S. 4021, 2021

Project-Website



This work is supported by the BMWK under the Project acronym QUAZE and Number: 16BZF361B

Acknowledgement: We would like to thank Christoph Blumenthal and Burak Cingoz at Zeiss GOM for their support in taking the initial characterization data with the DIC system.

PRECITEC



Centre for Renewable Energy
Albert-Ludwigs-Universität Freiburg

Gefördert durch:



aufgrund eines Beschlusses des Deutschen Bundestages